


Thank You for Choosing Our Product!



L-Trac Quick Start

1044 Pioneer Way, Suite F

El Cajon, CA. 92020

Phone: 619-579-1762

Fax : 619-579-1764

www.clearlysuperiortech.com

All products are thoroughly tested by experienced, professional technicians. All Clearly Superior trackballs are built and designed in the USA. If any trackball arrives with a problem, contact the reseller you purchased from first. If any problems exist after 30 days, contact us either by phone or at Sales@clearlysuperiortech.com

Compatibility: Windows 98SE and later, including Windows XP, Vista Win7, MAC OS9.8 and later, and all operating systems that are USB 2.0 Full Speed.

Installing Trackballs: Simply plug the trackball into any available USB port on your computer. Drivers will load automatically. Wait a few moments and roll the ball to test the connection. Some systems may play a sound after successfully starting the device.

Installing Superior-X Button Control: To Install Superior-X button Control, you may select "Install Superior-X: on the L-Trac index page, or you may locate the "Setup" file in the Superior-X folder on the CD.

FAQ's:

What do I do if the trackball feels rough? If the ball begins to feel rough after some use, spin the ball very fast in several directions. This will usually eject any dirt from the surface of the rollers. See "Cleaning Instructions" for further information.

How do I use the Adjustable Resolution?

Resolution switching is done by pressing and holding the center button and then clicking the right button. Each time this is done, the resolution (default on first power on = 800 CPI) will toggle to the next resolution. At first plug-in, it will be at 800CPI, perform the above action and it will switch to 1600CPI, do it again and it will go to 400CPI, repeat and it will go back to 800 and so on. It is not necessary to release the center button if you want to advance by two settings, in other words, you may press

and hold the center button and click the right button until you reach the desired resolution and then release the center button.

What do I do if I loose the Cd with Superior-X?: Superior-X can be downloaded from our website, please email: sales@clearlysuperiortech.com

Can I get replacement parts for my trackball?: In the unlikely event you should ever need spare parts such as a ball, hubs, bearings or cables , please contact our [sales department](#).